

Wet cleaning wipes in a box with dispenser, for final cleaning during service and assembly work in workshops, industry and construction

Application areas	<p>Highly effective, tear-resistant cleaning cloths for the final cleaning of numerous surfaces</p> <ul style="list-style-type: none">▪ for cleaning tools, fittings, metal, glass, plastics and painted surfaces▪ for cleaning parts during the assembly or disassembly of appliances, machines and motors etc.▪ remove stubborn dirt quickly, thoroughly and gently, like fresh adhesive and sealant residues, greases, oils, lubricant, tar, wax, soot, colour, ink, printing colour, graffiti etc.▪ absorb the dissolved dirt particles and bind them▪ ideal for all professional users in trade and industry (building craft, window and door construction, machinery and apparatus engineering, engineering industry, heating system construction, maintenance service, vehicle workshops etc.)
Product benefits	<ul style="list-style-type: none">▪ fast, excellent cleaning effect▪ remains moist for a long time▪ does not attack practically any surfaces▪ lint free▪ tearproof▪ antistatic▪ no unpleasant odour
Base	<p>White cellulose made of viscose / polypropylene, soaked with aqueous cleaning solution.</p>
Restrictions	<p>Not recommended for degreasing before bonding / sealing. Our range of products offers you a choice. For painted and delicate surfaces, test on an inconspicuous area beforehand.</p>
Self-tests	<p>Due to the wide variety of surfaces and color formulations used in the field, in-house testing is required.</p>
Processing	<p>Take the lid off the dispenser and remove the sealing film. Die ersten Tücher von der Mitte der Dose herausziehen und durch die Öffnung im Deckel drücken. Close the lid tightly again and open the sealing cap. Pull out the first cloth and tear it off at the perforation. Close the lid immediately after use to prevent the wipes from drying out. Clean the required parts. After each use, close the dispenser box tightly again. Nach jedem Gebrauch Spenderbox wieder dicht verschliessen.</p>
pH-value	<p>5.5</p>
Ignition temperature	<p>>55 °C</p>
Product data	<p>Size: ca. 300 x 250 mm Surface weight: ca. 35 g/m² (without soaking)</p>
Item no. + Delivery form	<p>RT 150.4 - dispenser box of 150 wipes Packing Unit of 4 dispenser boxes</p>

Further information



More information about this product (current technical data sheet, safety data sheet, certificates, product variants, etc.) can be found via the adjacent QR code.

Shelf life

In closed original packaging, protected from direct sunlight and stored in a dry place between +15 °C and +25 °C, the official shelf life is at least 12 months from date of production (the printed expiry date is decisive).

Safety and disposal: Familiarise yourself with the valid Safety Data Sheets (SDS) for the products used. All applicable safety regulations and disposal instructions must be observed.

Observe: All information is based on careful examinations in the labs and our previous practical experience. They are non-committal notes. Due to the many materials that are marketed and the different processing methods, which we cannot influence, we can, of course, not assume any warranty, including under patent-law, for the result of your work. We recommend performing sufficient own tests to find out if the product meets the respective requirements. In addition, we refer to our terms and conditions of sale, delivery and payment, available at www.wisabax.ch/agb.html. © Wisabax AG - This technical data sheet replaces all older versions.

Have you noticed an unclear formulation or an error? Thank you for your feedback. In case of doubt, the German version of the technical data sheet applies.